

# CC864/UC864 Windows CE 6.0 User Guide

1vv0300821 rev. 3 - 2011-02-24



**Disclaimer**

The information contained in this document is the proprietary information of Telit Communications S.p.A. and its affiliates ("TELIT"). The contents are confidential and any disclosure to persons other than the officers, employees, agents or subcontractors of the owner or licensee of this document, without the prior written consent of Telit, is strictly prohibited.

Telit makes every effort to ensure the quality of the information it makes available. Notwithstanding the foregoing, Telit does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information.

Telit disclaims any and all responsibility for the application of the devices characterized in this document, and notes that the application of the device must comply with the safety standards of the applicable country, and where applicable, with the relevant wiring rules.

Telit reserves the right to make modifications, additions and deletions to this document due to typographical errors, inaccurate information, or improvements to programs and/or equipment at any time and without notice. Such changes will, nevertheless be incorporated into new editions of this application note.

Copyright: Transmittal, reproduction, dissemination and/or editing of this document as well as utilization of its contents and communication thereof to others without express authorization are prohibited. Offenders will be held liable for payment of damages. All rights are reserved.

Copyright © Telit Communications SpA 2009.





## Applicable Products

Product
UC864-E
UC864-E-DUAL
UC864-E-AUTO
UC864-G
UC864-K
UC864-WD
UC864-WDU
CC864-DUAL
CC864-SINGLE



## Contents

<b>1. Introduction .....</b>	<b>6</b>
1.1. Scope .....	6
1.2. Audience .....	6
1.3. Contact Information, Support .....	6
1.4. Product Overview .....	6
1.5. Document Organization .....	7
1.6. Text Conventions .....	7
1.7. Document history .....	7
<b>2. System setup .....</b>	<b>9</b>
2.1. General Overview .....	10
2.2. Pre-requirements .....	12
2.3. Adding CC864/UC864 support in the OS image -Using the binary .....	14
<b>3. Using the CC864/UC864 .....</b>	<b>16</b>
<b>3.1. The serial API .....</b>	<b>16</b>
3.1.1. CreateFile .....	16
3.1.2. WriteFile .....	18
3.1.3. ReadFile .....	19
3.1.4. CloseHandle .....	21
<b>3.2. PPP Connection .....</b>	<b>22</b>



## 1. Introduction

### 1.1. Scope

This user guide serves the following purpose:

- Provides details about the CC864/UC864 Telit Modules.
- Describes how to compile, include in a kernel image and use the CC864/UC864 Windows CE 6.0 driver for a headless system.

### 1.2. Audience

This User Guide is intended for software developers who develop applications using CC864/UC864 modem.

### 1.3. Contact Information, Support

For general contact, technical support, to report documentation errors and to order manuals, contact Telit's Technical Support Center (TTSC) at:

[TS-EMEA@telit.com](mailto:TS-EMEA@telit.com)  
[TS-NORTHAMERICA@telit.com](mailto:TS-NORTHAMERICA@telit.com)  
[TS-LATINAMERICA@telit.com](mailto:TS-LATINAMERICA@telit.com)  
[TS-APAC@telit.com](mailto:TS-APAC@telit.com)

Alternatively, use:

<http://www.telit.com/en/products/technical-support-center/contact.php>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<http://www.telit.com>

To register for product news and announcements or for product questions contact Telit Technical Support Center (TTSC).

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.

### 1.4. Product Overview



## CC864/UC864 Windows CE 6.0 Software User Guide

lvv0300821 rev.3 - 2011-02-24

UC864 modules contains a fully featured HSDPA modem and UMTS/GSM/GPRS module, compatible with the other Telit GSM/GPRS modules.

CC864 modules contains a fully features CDMA modem compatible with the other Telit GSM/GPRS modules.

### 1.5. Document Organization

This manual contains the following chapters:

- "Chapter 1, Introduction" provides a scope for this manual, target audience, technical contact information, and text conventions.
- "Chapter 2, System setup" describes how to add the CC864/UC864 USB driver in a Windows CE 6.0 image.
- "Chapter 3, Device Driver" describes how to use the CC864/UC864 driver for interacting with the CC864/UC864 modem.

### 1.6. Text Conventions

This section lists the paragraph and font styles used for the various types of information presented in this user guide.



**Danger - This information MUST be followed or catastrophic equipment failure or bodily injury may occur.**



**Caution or Warning - Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.**



**Tip or Information - Provides advice and suggestions that may be useful when integrating the module.**

Format	Content
Arial monospaced	Windows CE shell commands at command prompt, filesystem paths, source code examples and menu items

All dates are in ISO 8601 format, i.e. YYYY-MM-DD.

### 1.7. Document history

Revision	Date	Changes
ISSUE #0	2009-04-10	First Release





CC864/UC864 Windows CE 6.0 Software User Guide  
1vv0300821 rev.3 - 2011-02-24

ISSUE #1	2009-10-08	Added support of all UC864 and CC864-DUAL Telit Modules
ISSUE #2	2010-07-14	Updated Applicability Table
ISSUE #3	2011-02-24	Update User bin guide





## 2. System setup


In this chapter it is described the general architecture of a Windows CE system with attached an CC864/UC864 module, the requirements needed for using the CC864/UC864 and how to integrate the CC864/UC864 device driver in a Windows CE image. The following table shows the reference platforms which this guide has been tested for:

Device	Operating System
AT92SAM9260	Windows CE 6.0 R2



## 2.1. General Overview

In the following image it is shown a diagram of USB software/hardware interaction in a Windows CE system with a CC864/UC864 attached:



From the bottom of the stack:

- Telit modem connected through an USB port.
- USB: serial bus for interfacing devices to a host computer.
- USB Host Controller: a combination of hardware and software that is responsible for the following actions:
  - o Detecting the insertion and removal of USB devices
  - o Managing flow control between the host and USB devices
  - o Managing data flow between the host and USB devices
  - o Collecting status



## CC864/UC864 Windows CE 6.0 Software User Guide

lvv0300821 rev.3 - 2011-02-24

- o Providing power to attached USB devices
- USB CC864/UC864 Device Driver: piece of software that allows the CC864/UC864 to be seen by the user application as connected through serial ports rather than USB port.
- Virtual serial ports (COM6, COM7, COM8 and COM9): serial ports created by the CC864/UC864 device driver for accessing the modem; they can be used as real physical serial ports.

UC864-E, UC864-E-AUTO, UC864-K, UC864-WD, UC864-WDU, CC864-K:

- o COM7: Telit HSDPA modem port, used for normal modem/application interaction (e.g. AT commands sending, data connection...).
- o COM8: Telit Diagnostics, used for firmware update.
- o COM9: Telit Auxiliary, used for debugging purposes.

UC864-G, CC864-DUAL:

- o COM6: Telit HSDPA modem port, used for normal modem/application interaction (e.g. AT commands sending, data connection...).
- o COM7: Telit Diagnostics, used for firmware update.
- o COM8: Telit NMEA, used for firmware update.
- o COM9: Telit Auxiliary, used for debugging purposes.

- User Application: piece of software written by the customer that uses CC864/UC864 features through virtual serial ports.




## 2.2. Pre-requirements

For correctly building a Windows CE 6.0 image with the CC864/UC864 USB driver on a headless system the following pre-requirements need to be satisfied:

- Microsoft Visual Studio 2005, with Platform Builder for CE 6.0.
- An OS design with the USB host controller supported.
- Knowledge of Windows CE OS image and subproject creation.

Please note that there are different ways for enabling the USB host controller and they depend on the considered hardware. In our test platform the USB host controller can be enabled during the initial image creation wizard (in the Core OS Services step), as the following image suggests:



Catalog Items View

Filter <Search>

- OSDesignUserGuide
  - BSP
    - Core OS
    - Device Drivers
    - Third Party
      - BSP
        - Device Drivers
          - Audio
          - Ethernet
          - GPIO
          - I2C
          - I2C\_EEPROM
          - Serial Driver
          - SPI
          - USB Function
          - USB Host
            - USB Host Controllers
            - USB Host
        - Ethernet bootloader
        - KITL
        - Saved Registry
        - Storage Drivers




## 2.3. Adding CC864/UC864 support in the OS image - Using the binary

For adding CC864/UC864 support in the OS image, having the binary *CDCDriver.dll*, follow these steps:

- In the *Solution Explore*, under the folder *Parameter Files* open the folders called as your BSP name and open the file *project.bib*. Under the *Modules* section add the following line:

```
CDCDriver.dll
$_(PROJECTROOT)\[path_where_the_dll_is]\CDCDriver.dll      NK
SHK
```


paying attention to change the path to the correct one (the place where the dll can be found).



## CC864/UC864 Windows CE 6.0 Software User Guide

1vv0300821 rev.3 - 2011-02-24

- Open the file *project.reg* and, at its end, paste the content of the file *CDCDriver.reg*.



- Recreate the OS image.

Now you should have the CC864/UC864 driver integrated into your OS image. Start your system with the just created OS image and, after the boot, plug the device into your target: if the connection succeeds you should see the three virtual serial ports described in paragraph 2.1 ready to be used.





## 3. Using the CC864/UC864

In this chapter it is explained how to programmatically use the CC864/UC864 (via the serial port API) and how to setup a PPP connection.

### 3.1. The serial API

Application can interact with the CC864/UC864 through the virtual serial ports created by the driver (for example COM7). Windows CE 6.0 has a complete API for dealing with serial ports; following you can find all the most important calls with code examples. Further information can be found in Microsoft Developer Network.

#### 3.1.1. CreateFile

This function creates, opens, or truncates a file, COM port, device, service, or console. It returns a handle to access the object.

Header:

winbase.h

Library:

coredll.lib

Syntax:

```
HANDLE CreateFile(  
    LPCTSTR lpFileName,  
    DWORD dwDesiredAccess,  
    DWORD dwShareMode,  
    LPSECURITY_ATTRIBUTES lpSecurityAttributes,  
    DWORD dwCreationDisposition,  
    DWORD dwFlagsAndAttributes,  
    HANDLE hTemplateFile  
);
```

Parameters:

*lpFileName*

[in] Pointer to a null-terminated string that specifies the name of the object, such as file, COM port, disk device, or console, to create or open.

*dwDesiredAccess*

[in] Type of access to the object. An application can obtain read-only access, write-only access, read/write access, or device-query access.

*dwShareMode*

[in] Share mode for the object. If this parameter is set to zero, the object cannot be shared. Subsequent open operations on the object fail until the handle is closed.

This parameter can be set to one or more values.

*lpSecurityAttributes*

[in] Not used.

*dwCreationDisposition*

[in] Action to take on files that exist, and which action to take when files do not exist.

*dwFlagsAndAttributes*

[in] File attributes and flags for the file.

*hTemplateFile*

[in] Ignored; as a result, this function does not copy the extended attributes to the new file.

Return Value:

An open handle to the specified file indicates success. If the specified file exists before the function call and `dwCreationDisposition` is set to `CREATE_ALWAYS` or `OPEN_ALWAYS`, a call to `GetLastError` returns `ERROR_ALREADY_EXISTS`, even though the function has succeeded. If the file does not exist before the call, `GetLastError` returns zero. `INVALID_HANDLE_VALUE`



indicates failure. To get extended error information, call GetLastError.

Example:

```
HANDLE hModem;  
hModem = CreateFile( TEXT("COM7:"),  
                    GENERIC_READ | GENERIC_WRITE,  
                    0,  
                    NULL,  
                    OPEN_EXISTING,  
                    0,  
                    NULL);  
if (hModem == INVALID_HANDLE_VALUE)  
    // error opening port; abort
```

Further information on the parameters' values can be found at <http://msdn.microsoft.com/en-us/library/aa914735.aspx>.

### 3.1.2. WriteFile

This function writes data to a file. WriteFile starts writing data to the file at the position indicated by the file pointer.

Header:

winbase.h

Library:

coredll.lib

Syntax:

```
BOOL WriteFile(  
    HANDLE hFile,  
    LPCVOID lpBuffer,  
    DWORD nNumberOfBytesToWrite,  
    LPDWORD lpNumberOfBytesWritten,  
    LPOVERLAPPED lpOverlapped  
);
```

Parameters:

*hFile*



[in] Handle to the file to be written to (returned by CreateFile). The file handle must have been created with GENERIC\_WRITE access to the file.

*lpBuffer*

[in] Pointer to the buffer containing the data to write to the file.

*nNumberOfBytesToWrite*

[in] Number of bytes to write to the file.

*lpNumberOfBytesWritten*

[out] Pointer to the number of bytes written by this function call. **WriteFile** sets this value to zero before taking action or checking errors.

*lpOverlapped*

[in] Unsupported; set to NULL.

Return Value:

Nonzero indicates success. Zero indicates failure.

Example:

```
#define BYTES_TO_BE_WRITTEN 4
char atTest[]="AT\r\n";
DWORD written;
HANDLE hModem;
hModem = CreateFile( TEXT("COM7:"),
                    GENERIC_READ | GENERIC_WRITE,
                    0,
                    NULL,
                    OPEN_EXISTING,
                    0,
                    NULL);
if (hModem == INVALID_HANDLE_VALUE)
    // error opening port; abort
if (!WriteFile(hModem, atTest, BYTES_TO_BE_WRITTEN, &written,
NULL))
    // error writing bytes; abort
```

Further information on the parameters' values can be found at <http://msdn.microsoft.com/en-us/library/ms892380.aspx>.

### 3.1.3. ReadFile

This function reads data from a file, starting at the position indicated by the file pointer.



Header:

winbase.h

Library:

coredll.lib

Syntax:

```
BOOL ReadFile(  
    HANDLE hFile,  
    LPVOID lpBuffer,  
    DWORD nNumberOfBytesToRead,  
    LPDWORD lpNumberOfBytesRead,  
    LPOVERLAPPED lpOverlapped  
);
```

Parameters:

*hFile*

[in] Handle to the file to be read. The file handle must have been created with GENERIC\_READ access to the file. This parameter cannot be a socket handle.

*lpBuffer*

[out] Pointer to the buffer that receives the data read from the file.

*nNumberOfBytesToRead*

[in] Number of bytes to be read from the file.

*lpNumberOfBytesRead*

[out] Pointer to the number of bytes read. **ReadFile** sets this value to zero before doing taking action or checking errors.

*lpOverlapped*

[in] Unsupported; set to NULL.

Return Value:

Nonzero indicates success. Zero indicates failure.

Example:

```
#define BYTES_TO_BE_WRITTEN 4  
#define BYTES_TO_BE_READ 9  
char atTest[]="AT\r\n";  
char atAnswer[10];
```



```

DWORD written;
DWORD read;
HANDLE hModem;
hModem = CreateFile( TEXT("COM7:"),
                    GENERIC_READ | GENERIC_WRITE,
                    0,
                    NULL,
                    OPEN_EXISTING,
                    0,
                    NULL);
if (hModem == INVALID_HANDLE_VALUE)
    // error opening port; abort
if (!WriteFile(hModem, atTest, BYTES_TO_BE_WRITTEN, &written,
NULL))
    // error writing bytes; abort
Sleep(500);
if (!ReadFile(hModem, atAnswer, BYTES_TO_BE_READ, &read, NULL))
    // error reading bytes; abort

```

Further information on the parameters' values can be found at  
<http://msdn.microsoft.com/en-us/library/ms891445.aspx>.

### 3.1.4. CloseHandle

This function closes an open object handle.

Header:

winbase.h

Library:

coredll.lib

Syntax:

```

BOOL CloseHandle(
    HANDLE hObject
);

```

Parameters:

*hObject*

[in] Handle to an open object.





Return value:

Nonzero indicates success. Zero indicates failure.

Example:

```
HANDLE hModem;
hModem = CreateFile( TEXT("COM7:"),
                    GENERIC_READ | GENERIC_WRITE,
                    0,
                    NULL,
                    OPEN_EXISTING,
                    0,
                    NULL);
if (hModem == INVALID_HANDLE_VALUE)
    // error opening port; abort
CloseHandle(hModem);
```

Further information can be found at  
<http://msdn.microsoft.com/en-us/library/ms923946.aspx>.

### 3.2. PPP Connection

There are several ways to setup a PPP connection for a Windows CE system; in this guide it is described one of the possible methods suitable for headless devices. For further instructions on how to create a subproject refer to MSDN (<http://msdn.microsoft.com/en-us/library/aa913961.aspx>).

- Open Visual Studio 2005 and load your Os Image Design solution.
- In the solution explorer create a Windows CE Console Application subproject with the source files provided by Microsoft in the directory, starting from your Windows CE root (typically WINCE600), \PUBLIC\COMMON\OAK\DRIVERS\NETSAMP\RASENTRY, compile it and add to the OS image. This program adds an entry to the default RAS phonebook from information stored in a configuration file.
- Create the RAS phonebook configuration file (for example called telitUC864.ras). In the directory, starting from your Windows CE root (typically WINCE600), \PUBLIC\COMMON\OAK\DRIVERS\NETSAMP\RASENTRY, there is the file *rasentry.txt* that explains the rules for creating this kind of file. Following there is an example:

Name=Telit RAS





```

UseCountryAndAreaCodes=N
Phone=[Your provider phone number]
SpecificIpAddr=N
SpecificNameServers=N
DeviceType=modem
DeviceName=Telit HSDPA Modem on COM7:
SwCompression=N
IpHeaderCompression=N
DialModifier=[Custom AT commands if needed]
SpecificNameServers=Y
DnsAddr=[Your provider primary DNS address]
AltDnsAddr=[Your provider alternative DNS address]

```

- Create a Windows CE Console Application subproject with the source files provided by Microsoft in the directory, starting from your Windows CE root (typically WINCE600), \PUBLIC\COMMON\OAK\DRIVERS\NETSAMP\RASDIAL compile it and add to the OS image. This program setups the PPP connection according to the selected RAS phonebook entry.
- Start your target and, after the boot, plug the UC864. Upload the created RAS phonebook configuration file to the target (for example using the File Viewer tool that you can find in the menu *Target → Remote Tools → File Viewer*).
- Launch in the target the application *RASENTRY* with the path of the RAS phonebook configuration file as the first argument; you can run an application in your system by choosing the menu voice *Target → Run Programs* and selecting the desired application.
- Launch in the target the application *RASDIAL* with the name of the created RAS phonebook entry (Telit RAS in the above example) as the first argument.

If all is successful the PPP connection should be setup: you can launch the *ipconfig* application for checking the target ip address.

